


1	2	3	4	5	6	7	8	9	10
Supply 24V ac/dc 110V ac/dc 220Vac/dc	External Push Button Button need to be activated to release Key. Do not keep activated.	Rectifier	Solionoid Unit 24Vdc 110Vdc 220Vdc	Fortress Switch Solionoid must be activated to Turn and Release Key	Contact 1 Normally Open	Contact 2 Normally Open	Contact 3 Normally Closed	Contact 4 Normally Closed	

### Revision History

Description	Rev:	Date	Initial	Approved

Drawn By: S Du Plessis	Checked By:	Approved/ Approved By	Approved Date:	Date Printed: 2021/05/07	Rev. A	Scale: NTS
			COPYRIGHT: This drawing is the property of DEEBAR and is not to be used wholly or in part prior to written consent of the company.			SS1 Unit
Drawing No:		24V:*3915.10, 110V:*3915.00 & 220V:*3915.14			Sheet: 1 OF 1	